

TRIPANE (TRP) SUSPENDED

INSTALLATION INSTRUCTIONS



IMPORTANT SAFETY INSTRUCTIONS

When installing or using this suspended fixture basic safety precautions should be followed

Read ALL INSTRUCTIONS before installing fixture.

- This fixture is intended for installation in accordance with the National Electric Code and Local and State Codes and must be installed by a licensed electrical contractor.
- DANGER - RISK OF SHOCK AND FIRE - DISCONNECT POWER BEFORE INSTALLATION

TRIPLANE (TRP) SUSPENDED

INSTALLATION INSTRUCTIONS

TYPICAL INSTALLATION

ALWAYS FOLLOW APPLICABLE BUILDING CODES WHEN INSTALLING ANY LIGHT FIXTURE. DUE TO PRODUCT VARIATIONS AND CONFIGURATIONS, THESE INSTRUCTIONS SERVE ONLY AS A GENERAL GUIDE.

REFER TO FACTORY PROVIDED SUBMITTALS FOR DETAILS

INSTRUCTIONS:

1. TURN OFF POWER AT FUSE BOX
2. Remove and set aside remote driver enclosure and suspension kit parts.
3. If joining multiple fixture sections together, remove the metal cover and loosen the set screws on joining bar hardware to extend and secure them.
4. Connect wires between fixture sections using connectors provided and push excess wire into fixtures. DO NOT PINCH WIRES BETWEEN THE PARTS.
5. Join sections together and secure joined fixtures with the joining hardware and set screws.
6. Install remote driver enclosure to building structure and attach building power using UL approved wire connectors. Connect the fixture neutral (white) to the supply neutral, connect the fixture line wire (black) to the supply line wire. Fasten ground wire (green) to ground wire. Push excess wires into the REMOTE DRIVER ENCLOSURE.
7. Remove cable gripper from suspension kit and connect it to the cables.
8. Install remaining cable suspension hardware to surface. Mounting method must support 50 lbs. Install canopy bracket to building junction box.
9. While supporting the fixture, attach suspension kit cable to installed cable gripper and adjust height so fixture is level. Joined sections may require re-adjusting joiner hardware if connection loosens during installation.
10. Insert cord through finial, canopy and canopy bracket. Attach cord to remote driver using the quick disconnect or using UL approved wire connectors. DO NOT CONNECT BUILDING POWER TO LED CORD. PERMANENT LED DAMAGE, RISK OF FIRE AND ELECTROCUTION WILL RESULT.
11. Push wires into junction box secure canopy with finial. DO NOT PINCH THE WIRES BETWEEN THE PARTS.
12. Install lens.
13. Turn on power.

